formetiq

Modena

Adjustment instructions



Seat height adjustment

Whilst seated locate the adjustment handle underneath the seat (RHS). Lift the inner paddle (twist handle clockwise) and the seat will lower. To raise the chair, lift the same paddle whilst taking your weight off the seat.



Optional adjustments

Headrest adjustment

Hold the headrest with both hands and pull up or push down to adjust height. Click the headrest forward/ backward to adjust the tilt to your desired angle.



Backrest height adjustment

Hold the backrest firmly with both hands and lift gently. You will hear a series of clicks. Raise to the desired height one step at a time. At the highest point the ratchet is released - the backrest will return to the bottom.



Armrest position adjustment

All armrests have a button on the outside. Depress this to raise or lower the arms to suit. There are nine positions to choose from. With multifunction armrests you can move the armrest pad forward/backward, left/right or rotate slightly to suit you.



Synchro mechanism tension adjustment

Whilst seated locate the adjustment handle underneath the seat (RHS). Twist clockwise to increase the resistance of the tilt mechanism or anticlockwise to reduce resistance. Adjust the chair to be in equilibrium to your own body weight.



Lumbar support depth adjustment

Available with mesh back only.
Locate the black adjustment
wheel in the central column of
the backrest frame. Rotate the
wheel anticlockwise to increase
the lumbar support depth and
increase pressure on your back.
Rotate the wheel clockwise to
reduce the lumbar support depth.



Backrest angle lock adjustment

Whilst seated locate the adjustment handle underneath the seat (LHS). Twist the handle clockwise to enable the backrest to recline. Twist the handle anticlockwise to lock the backrest in one of three locking positions.



Seat depth adjustment

Whilst seated locate the button directly underneath the seat (front LHS). Depress the button to release the seat and slide it to your desired position. There are six positions to choose from. The sprung mechanism will automatically return the seat back to min. depth when the lever is raised with no weight on the seat.

